

# Pupitast Satovi

### Fühlhebelmessgerät

- DIN 2270
- HM-Kugel 2 mm
- Einspannschaft  $\varnothing$  8 mm
- Tastarm automatisch umkehrbar
- inkl. Etui



#### Horizontal/horizontal

> mm <	mm	$\varnothing$ mm	No.
0,8	0,01	32	281-11
0,2	0,002	32	281-21
0,8	0,01	40	281-31
0,2	0,002	40	281-41

#### Vertikal/vertical

> mm <	mm	$\varnothing$ mm	No.
0,8	0,01	32	281-51
0,2	0,002	32	281-61
0,8	0,01	40	281-71
0,2	0,002	40	281-81

### Dial test indicator

- DIN 2270
- carbide ball 2 mm
- stem diameter 8 mm
- autoally reversing arm
- incl. box



281-11



281-51

### Fühlhebelmessgerät

- Werksnorm
- Messeinsatz  $\varnothing$  2 mm
- Einspannschaft  $\varnothing$  4 mm und 8 mm
- Tastarm automatisch umkehrbar
- inkl. Etui

#### Horizontal/horizontal

> mm <	mm	$\varnothing$ mm	No.
0,8	0,01	32	281-10
0,2	0,002	32	281-20
0,8	0,01	40	281-30
0,2	0,002	40	281-40

#### Vertikal/vertica

> mm <	mm	$\varnothing$ mm	No.
0,8	0,01	32	281-50
0,2	0,002	32	281-60
0,8	0,01	40	281-70
0,2	0,002	40	281-80

### Dial test indicator

- factory standard
- probe tip diameter 2 mm
- stem diameter 4 mm and 8 mm
- autoally reversing arm
- incl. box



281-10



281-70

> mm <    Messbereich  
    Ablesung  
 $\varnothing$     Gehäusedurchmesser    Range  
          Reading  
          Outside diameter